

## IC-F3400D series IC-F4400D series IC-F5400D series IC-F6400D series

Thank you for choosing this Icom product. **READ THIS INSTALLATION GUIDE** carefully and completely before connecting the transceiver and the PC using a Micro-USB cable.

### NOTE:

- When installing the software, confirm Windows has completed its startup, and then log in as the **administrator**.
- These instructions are based on using Windows 7.
- The displayed indications or operations may differ slightly from these instructions, depending on your Operating System (OS), its service pack level, or system settings.

## SYSTEM REQUIREMENTS

A PC with an OS and specifications and other items listed below are required to install the USB driver for the IC-F3400D, IC-F4400D, IC-F5400D, and IC-F6400D series transceivers.

### OS:

Microsoft® Windows® 8.1 (32/64 bit)\*

Microsoft® Windows® 7 (32/64 bit)


\* Except for the "RT" version.

### Others:


- A USB 1.1 or 2.0 port
- A CD drive
- A Micro-USB cable (user supplied)

## DRIVER INSTALLATION

1. Confirm no other applications are running.
2. Connect a transceiver to your PC with the Micro-USB cable.
3. Turn ON the transceiver.
  - "Installing device driver software" is displayed.




- Then "Device driver software was not successfully installed" is displayed.




4. Insert the CD into the CD drive.

5. Click the Windows "START" icon, right-click "Computer," and then click "Properties."
  - The "Control Panel Home" window is displayed.




6. Click "Device Manager."
  - The "Device Manager" window is displayed.




Continued on the next page.

## DRIVER INSTALLATION (continued)


7. Confirm a warning symbol “⚠” is on “ICOM Radio,” as shown below.




8. Right-click on “ICOM Radio,” and then click “Update Driver Software.”




9. Click “Browse my computer for driver software.”



10. “Browse for driver software on your computer” is displayed. Click <Browse...>.




11. Click the “USB\_DRIVER” folder of the CD, and then click <OK>.




12. Click <Next> to start the installation of the driver.

**NOTE:** If the “Windows Security” window is displayed, click <Install>.



13. After the installation is completed, “Windows has successfully updated your driver software” is displayed. Click <Close>.



14. Eject the CD from the CD drive, and then restart the PC.

Icom, Icom Inc. and the Icom logo are registered trademarks of Icom Incorporated (Japan) in Japan, the United States, the United Kingdom, Germany, France, Spain, Russia, Australia, New Zealand, and/or other countries.

Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.  
All other products or brands are registered trademarks or trademarks of their respective holders.